



# JUMPER HARNESS CH-7, CH-8 AND CH-9 Wire Harness

Installation Instructions for Part #6001020 & #6002021

## Warning!

WE RECOMMEND AUTO TECHNICIAN INSTALLATION FOR THE FUEL SYSTEMS

For tech help call 248.398.2397

***SAFETY FIRST YOU SHOULD HAVE THE FOLLOWING TOOLS:***

1. Fire extinguisher
2. Eye goggles
3. Gloves

**THE OEM FUEL SYSTEM IS UNDER PRESSURE. OPEN THE GAS CAP TO RELIEVE THE FUEL PRESSURE.**

You can refer to your service manual for more information. When upgrading to new injectors you will need to do The following:

1. Before you start, disconnect the negative battery cable
2. ***MAKE SURE THE PRESSURE IS RELIEVED (BEFORE YOU REMOVE THE FUEL RAILS)***
  - A. Push Schrader Valve to release pressure
  - B. Place a clean towel to prevent any gasoline that may spill during removal.
  - C. **CAUTION GAS WILL SPRAY OUT OF RAILS**
3. Make sure the vehicle is supported; room must be well-vented and no open flames.
4. Unplug the OEM fuel injector wiring harness
5. Plug male connector into the OEM wire harness plug make sure it snaps in good.
6. Plug female connector into the new fuel injector
7. Reconnect the negative cable back to the battery and put the fuel cap back on.
8. You may have to turn the key on and off two or three time **WITHOUT STARTING THE ENGINE,** until your fuel pressure gauge reads a least 40 PSI then check for any fuel leaks from the rail

PART # 6001020 (CH-7)



PART # 6002020 (CH-8)



OB2 \*\* NOTE IF YOU ARE USING CH-9 USE THE ZIP TIE AROUND OEM AND CPR PLUG \*\*